



Installation of Discharge Hose



- 1) Insert either end of flexible hose in outlet under handle.
- 2) Rotate hose counter clockwise until secure.

Cleaning Pump

Step 1



Step 2



- 1) Pry off cap at bottom of pump.
- 2) Press cap back on after cleaning.